

RUST-OLEUM[®]
INDUSTRIAL



7200NS FLOORCOAT PU

Single pack anti-slip floor coating

- For foot traffic, interior and exterior
- Anti-slip additive is premixed in the coating
- For use on concrete (>2yrs), metal and wood
- Touch dry after 4 hours
- Apply a 2nd coat to increase the antislip properties

footer_main_page_line_one

footer_main_page_line_two

7200NS FLOORCOAT PU

POPIS PRODUKTU (DLHÝ)

Anti-slip polyurethane-modified floor coating, abrasion resistant and easy to apply. 1K

ODPORÚČANÉ POUŽITIE

Floorcoat PU 7200NS can be applied directly on interior or exterior concrete floors (see surface preparation), wooden floors and masonry which are completely clean and dry. It is not recommended to apply on smooth/dense concrete or concrete containing a damp repellent additive, which will prevent a good adhesion. Floorcoat PU (7200NS) can also be applied on old good adhering coatings and can also be applied onto metal floors which have been correctly prepared and primed with a suitable Rust-Oleum metal primer.

TECHNICAL DATA

Hustota (g/cm³): 0,9-1,2
Obsah pevných látok v objeme: 45%

DRY TIMES BY 20

Na dotyk suché: 4h
Suché na manipuláciu: 8h
Suchý na opätovné natieranie: 24h
Úplne vytvrdené: 1 week

ODPORÚČANÁ HRúbKA MOKRÉHO FILMU

110 µm

ODPORÚČANÁ HRúbKA SUCHÉHO FILMU

50 µm

TEORETICKÁ SPOTREBA

9 m²/l

PRAKTICKÁ VÝDATNOSŤ

Practical coverage depends on many factors such as porosity and roughness of the substrate and material losses during application.

PRÍPRAVA POVRCHU

Remove oil, grease and other contaminations with Rust-Oleum ND14 Cleaner/Degreaser or high pressure (steam) cleaning in combination with appropriate detergents. Sand old intact coatings to roughen the surface in order to establish a good adhesion. Check the compatibility with old intact coatings. During application the surface should be dry and clean. On porous concrete a first coat should be applied with 7200NS diluted with ± 5% Thinner 633. Ensure concrete is at least 28 days old and moisture content lower than 6%. Remove curing compounds by means of dust free blasting or acid etching with Rust-Oleum SE108.

NÁVOD NA POUŽITIE

To ensure homogeneity, coating materials should be thoroughly stirred prior to use.

PODMIENKY APLIKÁCIE

Apply in a dry and well-ventilated area.

APLIKÁCIA A RIEDENIE: ŠTETEC

Dilute sparingly, if required, with 5% volume Thinner 633.

APLIKÁCIA A RIEDENIE: VALEC

Dilute sparingly, if required, with 5% volume Thinner 633. In case of roller application it can be necessary to apply 2 coats in order to obtain the recommended film thickness.

ČISTENIE ZARIADENIA / POSTRIEKANIE

Immediately after application with Thinner 633.

POZNÁMKY

Do not apply Floorcoat PU (7200NS) on highly alkaline substrates, or in areas which will be constantly under water.

SKLADOVATEĽNOSŤ

Minimum of 5 years from date of production in unopened cans, if stored in dry, well ventilated areas, not in direct sunlight at temperatures between 5° and 35°C.

last_updated: 07/02/2025

footer_data_colors_pack_sizes: footer_data_colors_pack_sizes.value

footer_data_disclaimer: footer_data_disclaimer.value

Rust-Oleum Netherlands B.V.
Zilverenberg 16
5234 GM 's-Hertogenbosch
The Netherlands
T : +31 (0) 165 593 636
F : +31 (0) 165 593 600
info@rust-oleum.eu

Tor Coatings Ltd (Rust-Oleum Industrial)
Shadon Way, Portobello Ind. Estate
Birtley, Chester-le-Street
DH3 2RE United Kingdom
T : +44 (0)1914 113 146
F : +44 (0)1914 113 147
info@rust-oleum.eu

Rust-Oleum France S.A.S.
38, av. du Gros Chiène
95322 Herblay
France
T : +33(0) 130 40 00 44
F : +33(0) 130 40 99 80
info@rust-oleum.eu

N.V. Martin Mathys S.A.
Kolenbergstraat 23
3545 Zelem
Belgium
T : +32 (0) 13 460 200
F : +32 (0) 13 460 201
info@rust-oleum.eu